



## INSTALLATION INFORMATION

- 1 - Decide on height of mirror, suggest 1940mm above finished floor level.
- 2 - Attach the top packing strip (marked top) at 1910mm from the finished floor level and bottom packing strip at 1140mm from finished floor level. (see drawing above.)
- 3 - Ensure your fixings (screw supplied) will be into studs or noggs.  
If this is not possible then use the raw plugs supplied. Liase with your local hardware supplier for alternate wall fixing system should your walls not be Gib.
- 4 - When you have secured packing strips to wall ensure they are level.

### Mirror Fixing Instructions

- Please follow fixing instructions supplied with mirror.

### Fixing Aria Light

- Attach the base of the light to the top packing strip (screws supplied) fixing into the two pre-drilled pilot holes.

### Connect Wiring

#### IMPORTANT

- The light fitting must be earthed as per the NZ wiring regulations.